

Camp Snap 8mm Digital Camera Instructions for use



Read these instructions carefully before using this product and keep them for future reference. You can also find these instructions, along with tips & tricks, on our website:

<https://autovision.nl/faq/camp-snap-digital-camera/>



Film filter choice



On/Off


Image
format

Record button

Sight

SD card
memory
capacity

3.5mm ext
microphone



Turn on the camera:

Switch the Power button to ON. You'll hear a beep, and the analog hands will move.

Set the video metadata date:

The first time you use the camera, you must set the correct time and date.

Look through the viewfinder.

Press and hold the MODE button to enter the date setting mode. Adjust it with the UP and DOWN buttons. Press the MODE button again to move to the next field.

After setting the year, the VOL box allows you to set the volume of the control beep: 0 = off, 1 = low, 2 = medium, 3 = high.

Shooting Video:

Look through the viewfinder and compose your shot. Press and hold the record button to start recording; a red indicator will flash in the viewfinder.

Release the button to stop recording.

Turning the camera off:

To turn the camera off

Set the mode switch to OFF. You will hear a beep, and the analog hands will return to 0.

Automatic camera power off:

The camera automatically turns off after 10 minutes of inactivity to conserve battery life.

Charging the camera:

To charge the camera, connect the USB-C cable to the camera and connect it to a (phone) charger or the USB-C port on a computer/phone.

The LED on the bottom is red while charging. When charging is complete, the LED on the bottom turns green.

Tips for shooting video:

- 1) With the camera off (analog dials at 0), turn the camera on as described in step 1.
- 2) For best results, stand at least 1 meter (3 ft) away from your subject and shoot in good lighting conditions with the sun behind you.

3) Hold the camera steady and press the record button. The viewfinder will display the recording time.

Choose your aspect ratio with the "Image Format" button.

Set your own style:

- 9:16 for reels
- 16:9 for cinematic widescreen
- 1:1 for square images, suitable for social media
- 4:3 for a classic home video look

To make it completely "retro," you can choose a film filter using the button:

- STD (Standard): Classic camcorder look. 30 frames per second, natural colors, no added effects.
- VTG 1 (Vintage 1): Soft, faded colors that look like they're straight out of the '90s. 30 fps
- VTG 2 (Vintage 2): Warm, nostalgic tones. 30 fps
- ANA (Analog): Textured and imperfect (with digital scratches and dust specks), just like real 8mm film. 8 fps.

Viewing/downloading videos:

- 1) Use the included USB-C data cable to connect the camera to a computer, laptop, tablet, or phone.
- 2) The LED next to the USB port is red.
- 3) Open File Explorer/Finder on your computer and navigate to the "CAMPSNAP" folder. On your phone, select USB>DCIM.
- 4) Copy or view the files as desired.
- 5) Once the videos have been copied, you can delete all files from the camera.
- 6) Safely disconnect the camera from the PC/tablet/phone (eject/unplug).

SD Card Video Storage:

Your Camp Snap 8mm camera comes pre-installed with a 4GB SD card that holds approximately 30 minutes of video. (Maximum 128GB SD card for approximately 180 minutes of video.)



To remove the SD card, turn off the camera, loosen the two Phillips screws on the bottom of the camera, and remove the cover.

Push the SD card in, and it will pop out.

Carefully insert the (new) card into the slot with the gold contacts facing the camera lens. Click it into place. Close the cover and replace the Phillips screws. SD cards up to 128GB are supported.

NOTE:

The camera is an electronic product and is not waterproof. Do not expose the camera to liquids; keep it dry.

Tech Info

Model number	CS-8 / Art 120008
Pixels	16 MP
Resolution	2880x2144
File format	MP4 H264
Image size	9:16 /16:9 /1:1/4:3
Lens	3.29mm f/2.0. Focal Length Equivalent (35mm) = 25.7mm (wide angle).
Focus	Fixed
Seeker	Plexiglass
Filters	5
Display	TFT 1.4inch
Resolution	320*320
Distance	0.5m> infinite
Zoom	8x Digital
Deviation	<1.5%
Sensor	½.7" CMOS
Frame rate	18-30fps
White balance	Automatic
Memory	4GB SD card good for approx. 30 min videos Max 128GB approx. 180 min
Info displays	Analog hands
Battery	Li-Ion 2500mAh for approx. 30-45 min video
Charging/data	USB C
Cold Shoe	Yes for accessories
Tripod connection	Yes ¼ inch
Dimensions	200 x 200 x 60 mm

Weight	480Gr
Operating temperature	-20C-60C

Troubleshooting

Failure	Solution
Does not turn on	Make sure the camera is fully charged
Doesn't play videos	Download videos according to the instructions
	Format or replace SD card
Camera is stuck, won't turn off	Press the reset button with a needle or toothpick. See page 3
Further questions	Take a look here: https://autovision.nl/faq/camp-snap-digital-camera/



WEEE (Waste Electrical and Directive)

WEEE (Waste Electrical and Electronic
Equipment Directive)



Please note that, as a consumer electronic device, your device is subject to the European Directive 2002/96/EC on the reduction of electronic waste. Therefore, you must not dispose of your device with your household waste. Information about the disposal of old devices is available from your local authority, your waste disposal service, and the store where you purchased this product. You can return your device free of charge to a municipal collection point. By disposing of old devices properly, you prevent environmental damage and pose no risk to your health.

Please note that, as the end user, you are obligated to return batteries to a retailer or a collection point established by the public authority responsible for waste disposal.

Disposing of batteries Check local regulations regarding battery disposal or contact your local authority, your waste disposal company, or the store where you purchased the product. Batteries must never be disposed of with normal waste. If available, use a battery recycling center in your area or community.

See <https://autovision.nl/support-autovision/recycle/> for more information.



Camp Snap Importer
Benelux:
Autovision Holding BV
Burgemeester
Engelbertsstraat 92
2042 KP Zandvoort
The Netherlands
Website:

www.autovision.nl

