



AV Melody ANC Pro True Wireless Earbuds

Dear music lover,

Thank you for purchasing the Autovision Melody ANC Pro TWS earbuds.

Please read this instruction manual before using it. For the best user experience, the AV Melody TWS Earbuds have ANC: Active Noise Canceling, this technology suppresses disturbing ambient noise. Transparency mode: amplifies ambient sounds, so you don't have to take the earbud out of your ear for a conversation. And Game Mode: Reduces the Bluetooth audio delay when playing videos. Wireless Charging of the case makes charging easy.

We wish you a lot of listening pleasure!
Team Autovision.



In the box


AV Melody – e-manual - EN02AVG\$

It is IMPORTANT to choose the correct ear tips size. Otherwise the Active Noise Canceling will not work properly and the bass will be missing.

Select the right size by trying it on.




FIRST USE – PAIRING



- 1) Place the earbuds in the charging case.
- 2) Wait for 15 minutes to charge the earbuds.
- 3) Open the charging case.
- 4) Go to Bluetooth menu in the phone and find “AV Melody ANC”
- 5) Select it and confirm the connection.

MUSIC CONTROL



Pause/play > 1x tap left or right

Previous track > 2 sec tap left*

Next track > 2 sec tap right

Google Assistant/Siri > 2x tap right

ANC, Transparency mode on/off:

ANC on > 2x tap left, Transparency mode > again 2x tap left, both off > again 2x tap left.

Game Mode on/off > 3x tap right

ANC: Active Noise Canceling

suppresses disturbing ambient noise


Transparency mode:

amplifies ambient sounds

Game Mode: Reduces the audio delay

*May vary with the media player used

PHONE CNTROL



Answer a call > 1x tap left or right


Hang up a call > 1x tap left or right

Reject call > 2 sec tap left or right

ANC, Transparency mode on/off:

ANC on > 2x tap left, Transparency mode >
again 2x tap left, both off > again 2x tap left.

CHARGING




USB C Charging Port

Charging charging case.

Wireless: place the charging case with the LED up on the charging mat.

With cable: insert the USB-C cable into the charging case at the bottom.

The LED indicates that the case is being charged.



LED Indicator

Orange > Charging case is charging

Green > Charging case is charged

White > Earbuds are charging

White flashes > Charging case battery empty

Charging earbuds:

Place the earbuds in the charging case. The white LED on the case indicates that the earbuds are being charged.

EARBUDS LED's

Both earbuds flash white quickly (after opening the case) > search for connection with paired phone, then connect automatically.

Both earbuds will flash white every 5 seconds when connected to phone.

Earbud(s) blinking twice every 20 sec > battery empty

The LED on the case lights up white when the earbuds in the charging case are being charged, goes off when they are charged.

TURN ON EARBUDS

Open the charging case, the earbuds will turn on
OR

Tap the earbuds for 2 seconds to manually turn them on.

TURN OFF EARBUDS

Place the earbuds in the charging case and close the cover.

OR

Tap the earbuds for 8 seconds to manually turn them off. (Power off)

CONNECTION RESET

Pairing does not work or 1 earpiece does not work. (Are the earbuds charged?)

Put the earbuds in your ear for a moment, so you can hear what's happening via the voice prompt.

Tap the earbuds for about 10 seconds to turn them off and reset. (so longer then Power Off)

Tap for about 2 seconds to turn the earbuds back on.

Place the earbuds in the charging case.

CLOSE the charging case

WAIT 5 secs

OPEN the charging case

Pair the AV Melody ANC with your phone again.

If necessary, first delete it in your Bluetooth phone settings and pair it again.

For the latest questions and answers:
Check out the FAQ of our website

<https://autovision.nl/support-autovision/>

TECH SPECS

Article: AV Melody ANC Pro

Battery life Earbud approx 9 hours (total approx 31 hours).

Charging: Wireless or USB-C

ANC: Active Noise Canceling -25db to - 27dB

Transparency mode: conversation poof

Game Mode: gives minimal audio delay in the bluetooth connection. For your information:

Game mode from 197ms.

Game mode at 60-80ms

(For comparison: Airpods Pro 114.5ms)

Touch control: next/previous song, pause, ANC, Transparency mode, Game mode, Siri/google assistant, Hands-free calling.

Driver 10mm.

Sensitivity 107 +/-3dB.

Distortion 1KHz <1%

Frequency 20Hz-20KHZ.

Bluetooth 5.0(Airoha 1562F chipset)

IPX rate IPX 4

Charging the case about 1.5 hours

Charging the earbuds about 1 hour

Battery life music 8-9 hours (with case 31.5 h)

Battery life with ANC 6 hours (with case 17.5 h)

Weight Earbud 6.8gr, Case 42gr.

Size Case: 63 x 45 x 25mm.

SAFETY INSTRUCTIONS

- High volume of the earbuds can damage your hearing.
- Do not place the earbuds in damp, dusty, vapor or steam areas or in direct sunlight.
- Do not leave the earplugs in the car for too long to avoid unnecessary problems.
- Do not put weight or pressure on the earbuds, otherwise the earbuds will deform if you store them for a long time.
- Avoid excessive impact on the earbuds.
- Do not soak the earplugs in water, they are only superficially waterproof, remember the following precautions:
 - Be careful not to drop the earbuds into places full of water.
 - Do not use the earbuds in a wet environment or rainy day.
 - Do not expose the batteries (the installed battery or batteries) to heat sources such as sunlight or fire for extended periods of time.

- Users of lithium batteries should not replace them themselves. When the battery has reached the end of its useful life, it must be disposed of in accordance with the applicable regulations.
- Please do not use it in a dangerous location unless you can hear the sounds around you.
- The earbuds and their small parts can be swallowed. Place the earbuds in the charging case after use and keep them out of the reach of children.

FAULTS / PROBLEMS

Earbuds not connecting	Put the earbuds back in the charging case, close it, wait 5 sec. open the charging case and try to connect again. If this does not work see "reset connection"
------------------------	---

Earbud doesn't work	<p>Are you charged?</p> <p>Place the earbuds in the charging case and check if the white case LED is on.</p> <p>If not, check the gold contacts on the earbuds to see if they are clean.</p>
A softer sound comes out of 1 of the earbuds.	<p>Check that there is no dirt, earwax, etc. in the earbud. You can usually see it in the rubber cap.</p>
Earbud is not charging	<p>Place the earbuds in the charging case and check if the white case LED is on. If not, check the gold contacts on the earbuds to see if they are clean. And the contacts in the charging case for dirt.</p>
No Bass	<p>Place eartips that seals well in your ear</p>



WEEE (Waste Electrical and Electronic Equipment Directive)

AEEA (Richtlijn voor Afval van Elektrische en Elektronische Apparaten)

Please note that as a consumer electronic device, your device is subject to the European Directive 2002/96/EC for the reduction of electronic waste.

Therefore, do not dispose of your device with household waste.

Information about the disposal of old appliances can be obtained from your municipal administration, the cleaning service and the store where you purchased this product. You can hand in your device free of charge at a municipal collection point.

Properly disposing of old appliances prevents damage to the environment and poses no risk to your health. waste disposal authority established return point.

Please bear in mind that as an end user you are obliged to hand over batteries to a retailer or to a return point established by the publicly responsible body for waste disposal.

Dispose of battery/batteries

Please check your local battery disposal regulations or contact your city hall or your waste disposal company or the shop where you purchased the product. The battery/batteries must never be disposed of with normal waste. Use a battery handling facility in your area or community if there is one.

For more information take a look at <https://autovision.nl/support-autovision/recycle/>

The manual in the Dutch, German and French language can be downloaded here

<https://autovision.nl/av-melody-anc-product-pagina/>

For the latest questions and answers:

Check out the FAQ of our website

<https://autovision.nl/support-autovision/>

Importer

Autovision Holding bv – Netherlands

www.autovision.nl